



Cable Installation through Limit Switch Assembly

Installing the power cable in a Cablemaster without disconnecting the limit switch assembly

STEP 1: REMOVE OFFSET BRACKET

Remove both bolts which fasten the Offset Bracket to the Limit Switch Assembly.



STEP 2: REMOVE HEX HEAD SCREWS AND ROLLER

Remove hex head screws which hold the Roller in place. Remove Roller and pin.



STEP 3: INSERT CABLE AND REASSEMBLE

Insert cable through open gap and reassemble Limit Switch. Attach Offset Bracket.

