

Cablemaster™ Model CRR

OPERATION & MAINTENANCE GUIDE

Congratulations! You are now the proud owner of a Glendinning power cord reel! Here are a few important things to know to get the best usage and enjoyment out of your cord reel!

EXTENDING YOUR CABLE

- Pull out sufficient cable length that will allow you to route cable to RV Park power post.
- Plug cable into receptacle. Ensure that the "Easy-Out" lever is folded down on the cord set and flush with the receptacle. Green LED on plug will turn on when sufficient power is present on both power wires.



QUICK TIP

You don't need to pull out all the cable! Only extend the length of cable you need for your connection!

RETRACTING YOUR CABLE

- Detach plug from RV Park power receptacle by lifting the bottom of lever on plug (see right).
- Press and hold Power Switch and the cord will retract. Release switch when the cable is fully retracted.
- To fully retract cable and to make payout easier, guide cable onto spool so that it "level winds" from left to right and then from right to left. The cable will require two layers of cable to be spooled onto reel.





RECOMMENDED MAINTENANO

- Check for dry and tight connections, no chaffed or cut wires, no exposed conductors.
- Be careful not to let the cord kink. If kinking happens, extend cord completely and retract back onto unit.
- Make sure that the unit is kept dry.
- Clean cable as needed (Most cleaners are compatible with power cable).
- If replacing power cable, make sure that cable is approved and rated 105c cable.
- Any adjustments or changes, other than normal maintenance, will void terms of warranty.

SAFETY INSTRUCTIONS

- Always disconnect from power when installing, removing motor cover, or doing maintenance.
- Not for outdoor use
- Be sure to use safety measures when children are near operating or nonoperating unit.
- Any wiring should be done by a qualified electrician.
- Always disconnect and fully retract before getting underway.

A CAUTION

Keep fingers out of cable path and mechanism when retracting

A WARNING

If power cable jacketing is damaged or bare wires are exposed DO NOT USE the cable. See contact information below.



For installation, operation, and warranty information, scan the QR code for your model:

Model CRR50



Model CRR50LP



www.GlendinningProds.com/CRR50

www.GlendinningProds.com/CRR50-LP



Glendinning Products, LLC 740 Century Circle Conway, SC 29526

GLENDINNI

(843) 399-6146 info@glendinningprods.com

(843) 399-5005

www.GlendinningProds.com